

MANTEL ASSEMBLY INSTALLATION INSTRUCTIONS

FULL CABINET MANTEL: EMF-22(C,DO,O,UH,W)-2
CORNER CABINET MANTEL: EMC-22(C,DO,O,UH,W)-2

INSTRUCTIONS MUST BE LEFT WITH THE OWNER FOR FUTURE REFERENCE AFTER INSTALLATION.

FULL MANTEL

1. Place base adjacent to gas inlet supply.
2. Install fireplace on to base and connect gas line.
3. Insert mantel sides to mantel base.
4. Use four (4) 1-1/4" wood screws, two (2) per side, to attach breast board to mantel sides.
5. Attach nail flange brackets to top of fireplace with two (2) 10 x 1/2" screws per bracket. Brackets and screws are supplied with fireplace.
6. Place mantel top onto breast board and mantel sides.
7. Assembly of mantel is completed.

CORNER MANTEL

1. Attach corner supports 37-1/2" from floor to top of support with 2-1/4" screws. If necessary wall anchors may be used.
2. Install fireplace on to base and connect gas line.
3. Insert mantel sides to mantel base.
4. Use four (4) 1-1/4" wood screws, two (2) per side, to attach breast board to mantel sides.
5. Attach nail flange brackets to top of fireplace with two (2) 10 x 1/2" screws per bracket. Brackets and screws are supplied with fireplace.
6. Place mantel top onto breast board and mantel sides.
7. Assembly of mantel is completed.

